



Blue  
mr Handsfree® Easy CK200

## User's Manual

GB NL D F

### PACKAGE CONTENTS & PARTS

#### See illustration I

- |                      |                  |                             |
|----------------------|------------------|-----------------------------|
| 1. MF-button         | 4. MUTE Button   | 7. Speaker                  |
| 2. Volume [-] Button | 5. LED indicator | 8. USB charging socket      |
| 3. Volume [+] Button | 6. Microphone    | 9. USB cable (for charging) |

### CHARGING THE BATTERY

1. Plug the USB cable (9) into the USB charging socket (8) of the Blue Easy CK200.
2. Plug the other end of the USB cable (9) into your computer or USB charger.
3. The red LED indicator (5) on the Blue Easy CK200 will light up and your Blue Easy CK200 will start charging. When fully charged, the red LED indicator (5) will turn off.

#### Attention!

Make sure that the Blue Easy CK200 is **fully** charged before using the device.

### TURNING ON / OFF

#### - Turning ON:

Press and hold the MF-button (1) until you hear a melody and the blue LED indicator (5) starts flashing.

#### - Turning OFF:

Press and hold the MF-button (1) until you hear a melody and the red LED indicator (5) lights up briefly before turning off again.

#### Attention!

The Blue Easy CK200 will also turn off automatically if there has been no Bluetooth® connection between the Blue Easy CK200 and another mobile device for more than 10 minutes.

### FIRST USE PAIRING

! You are required to pair the Blue Easy CK200 with your mobile phone once before using it!  
Make sure that the Blue Easy CK200 is turned OFF. → Press and hold the MF-button (1) until the LED indicator (5) starts flashing by blue and red colors alternately. → Let your phone search for Bluetooth® devices. → Select the Blue Easy CK200 in your mobile phone and enter the PIN code 0000[\*] to pair both devices. You will hear a long beep. → The blue LED indicator (5) will light.

(\*Usually not required for Bluetooth® 2.1 mobile phones)

#### Attention!

- Make sure that the Bluetooth® function of your mobile phone is ON and that it is in close proximity to the Blue Easy CK200 carkit.
- To ensure automatic reconnection between the phone and the Blue Easy CK200, we recommend setting the Blue Easy CK200 as "Authorized" in the Bluetooth® menu of your phone! Please refer to the manual of your mobile phone for more detailed information.
- If the Bluetooth® connection is not restored automatically after disconnection, press the MF-button (1) once to restore the connection manually.

### MAKING CALLS

- **Incoming call:** Press 1x MF-button (1) to ANSWER a call.
- **Incoming call:** Press and hold MF-button (1) [2 sec.] to REJECT a call.
- **During a conversation:** Press 1x MF-button (1) to END a call.
- **During standby mode:** Press and HOLD Volume [+] button (3) to REDIAL the last dialed number.
- **During standby mode:** Press 1x MF-button (1) to activate voice dialing [\*]

(\*The voice dialing function is only available if it is supported by your mobile phone!)

### VOLUME / MUTE

#### - Adjusting the volume:

Press "+" (3) to increase the volume level. You will hear a beep when max. volume is reached.

Press "-" (2) to decrease the volume level. You will hear a beep when lowest volume is reached.

#### - Turn ON MUTE mode:

During a conversation, press and hold the MUTE- button (4) for 3 sec. to temporarily turn off the microphone of the Blue Easy CK200.

#### - Turn OFF MUTE mode:

Press and hold the MUTE Button (4) for 3 sec. to turn the microphone back ON.

### MULTIPOINT BLUETOOTH®

Blue Easy CK200 supports MULTIPOINT BLUETOOTH®, which allows you to connect and use 2 different Bluetooth® telephones AT THE SAME TIME with your carkit.

When 2 phones are connected to the Blue Easy CK200 you always have:

- Primary phone (1st phone connected to the carkit)
- Secondary phone (2nd phone connected to the carkit)

## DECLARATION OF CONFORMITY

Hereby,

Company:	TE-Group
Address:	Kapelsestraat 61, 2950 Kapellen - Belgium

declare, that the following equipment:

Product Name:	Mr Handsfree Blue Easy CK200
Product Type:	Bluetooth® Carkit

Complies with the essential requirements, which are specified in the Directive 2004/108/EC, 2006/95/EC and 1995/5/EC on the approximation of the laws on the Member States relating to electromagnetic compatibility.


This product has been tested against following standards and specifications, applying versions valid on November 23rd, 2011:

ETSI EN 301489-1 V1.9.2 (2011-09)  
ETSI EN 301489-17 V2.1.1 (2009-05)  
ETSI EN 300328 V1.7.1 (2006-10)  
EN 60950-1: 2006+A11: 2009+A1: 2010

Joseph Van Oosterum, CEO TE-Group, July 2013



## ILLUSTRATION I



Manual/MRH-BlueEasyCK200/04-14/V02

Copyright© mr Handsfree.

GB

#### Attention!

NO Voice dial, NO redial possible for 2nd phone.

#### Multipoint pairing procedure

##### ► PAIRING phone 1

Pair the 1st phone with the Blue Easy CK200 as described under "FIRST USE PAIRING". → Connect the phone to the carkit.

##### ► PAIRING phone 2

Make sure Blue Easy CK200 is ON and connected to the 1st phone. → Press and hold the Volume [-] button (2) of the Blue Easy CK200 to enter pairing mode again. The blue & red indicators will flash alternately. → Pair and connect with the 2nd phone.

#### Attention!

After the 2nd phone is paired and connected, the 1st phone will be DISCONNECTED from the carkit. → Turn OFF the Blue Easy CK200 and then turn ON again, by using the MF-button (1). → Blue Easy CK200 will reconnect with both phones automatically.

#### Multipoint Connection Procedure

When the Blue Easy CK200 is switched on, it will automatically search and connect with the 2 last mobile phones that had Bluetooth® connection with the carkit.

- If only 1 phone is available: only one phone will be connected to the Blue Easy CK200. This phone will be the primary phone.

- One or both phones are shortly disconnected: the carkit will automatically reconnect.

#### Attention!

To ensure automatic reconnection between the phones and the Blue Easy CK200, we recommend setting the Blue Easy CK200 as "Authorized" in the Bluetooth® menu of your phone! Please refer to the manual of your mobile phone for more detailed information.

If for any reason one of the 2 phones, or both phones, will spontaneously lose the Bluetooth® connection with the Blue Easy CK200, it will automatically make a reconnection. If this automatic reconnection fails, you can always restore the Bluetooth® connection manually by pressing the Volume [+] button (3) for 3 seconds.

#### Receiving calls on the 2 phones

If during a telephone conversation another incoming call is received on the 2nd phone, you will hear a BEEP.

Now you can:

► **Answer the incoming call on 2nd phone:** Press and hold the Volume [+] Button (3) shortly to HOLD the call on the 1st phone and answer the call on the 2nd phone.

When you have accepted the 2nd call, you can:

► **Switch between 2 phones:** Press and hold the Volume [+] Button (3) briefly to switch between the 2 phones.

► **End one of the calls:** Press the MF-button (1) once to end the current call and continue with the other call.

### LED INDICATOR (5)

#### Red indicator:

- Flashes in Standby mode: low battery capacity.
- Lights continuously while charging the battery.
- Lights continuously in mute mode.

#### Blue indicator:

- Flashes in Standby mode & talking mode.

#### Red & Blue indicators:

- Flash alternately in pairing mode.

### MICROPHONE (6)

Make sure that the microphone (6) is directed towards your mouth. For optimum performance, the microphone (6) should be located at a distance of 30-50 cm from the driver's mouth. Make sure that there are no obstacles in front of the microphone (6) of the Blue Easy CK200.

### CUSTOMER SUPPORT

For more information, technical questions and return requests concerning this product, you should contact support@mrhandsfree.com.

### GUARANTEE

Mr Handsfree is a registered trademark of TE-Group NV. The mr Handsfree brand stands for superior product quality and outstanding customer service. That is why mr Handsfree warrants this product against all defects in material and workmanship for a period of two (2) years from the date of original purchase of the product. The conditions of this guarantee and the extent of responsibility of mr Handsfree under this guarantee can be downloaded from our website: [www.mrhandsfree.com](http://www.mrhandsfree.com).